


# ULINE S-3823, S-3824, S-257 PLASTIC BUCKLES

## INSTRUCTIONS FOR THREADING PLASTIC BUCKLES



**STEP 1** Insert end of strapping up through center of the buckle and around open leg to form a loop. Pull top tight around leg.




**STEP 2** Wrap strapping around package. Loop strapping around remaining open leg of buckle. Pull loop tight around leg.



**STEP 3** Pull both top ends of strapping in the opposite direction to manually tighten.

## INSTRUCTIONS FOR USING TENSIONER/CUTTER TOOL



**STEP 1** Place strapping between tensioner rods.



**STEP 2** Raising the handle, rotate tool 360°. Pull tool to desired level of tension.



**STEP 3** Use blade side of tool. Cut away excess strapping.

FOR FURTHER ASSISTANCE, PLEASE CALL ULINE  
CUSTOMER SERVICE AT 1-800-295-5510  
[uline.com](http://uline.com)